

MPA3 V6.2 Motor Protection Relay for Mining Applications

1. Description

The Ampcontrol MPA Motor Protection Relay has been designed, for use in a mining environment, to provide optimum overload protection of small to medium sized 415 V motors used on conveyors, pumps, fans and compressors. It can also be used with higher voltage motors. In addition to motor protection the relay has features to monitor temperature, provide alarms before a trip condition and through a 50 record event log allows diagnosis of a problem after a fault has occurred. An optional insulation test module (MPA-I) allows frequent testing of motor insulation.

The standard current transformers supplied with the MPA Protection Relay enable protection of motors with full load currents ranging from 5.125 A to 640 A. The selected full load current can be set to one of 224 values across the range. The settings prefixed by A automatically reset a motor overload trip once the thermal accumulator falls below the set value. Otherwise the trip has to be reset manually by pressing the keypad 'RESET' button or activating the 'RESET' digital input once the thermal accumulator has fallen below the set value.

The MPA Motor Protection Relay has 5 digital inputs, which feed into a microprocessor unit. The microprocessor has been programmed to control three output relays: MTR (Main Trip Relay), ALM (Alarm Relay) and AUX (Auxiliary Relay). Inputs are also provided for PTC Thermistors and current transformers.

A two-line backlit LCD display combining with a keypad provides an easy to operate user interface. The display provides easy access to all available information. A simple procedure allows adjustment of the relay's settings.

The Energy Storage Module allows the MPA Relay to function normally for a period of two (2) seconds during an extreme power dip or power loss.

The MPA's event log and adjustable settings are battery backed with an approved IS Battery (AUS Ex 01.2533X Ex ia I). The battery is not user replaceable (return the MPA Relay to Ampcontrol for replacement of the approved battery).

An optional monitoring module (MPA-M) can be utilised to provide the following features:

- Five PT-100 RTD inputs, which are arranged in two groups, three for the stator and two for the bearings.
- RS485 Modbus RTU communication port that can be connected to Motor Starter PLC's or a central monitoring system for continuous monitoring and fault-finding.
- A 0-20 mA / 4-20 mA Analogue Output.

Alternatively; optional monitoring module MPA-M (e) may be used to provide the same features as those of optional monitoring module MPA-M except the RS485 Modbus communication port is replaced by an EtherNet/IP communications port.

The MPA is housed in an enclosure suitable for flush mounting in a 135mm square cut out and has robust plug in connectors on the rear.

See MPA User Manual 143401 for full details.

2. Protection Functions

The Ampcontrol MPA motor Protection Relay provides protection functions for:

- Overload
- Short Circuit

(Continued next column)



- Earth Leakage (Designed and Tested to AS2081.3-1988)
- Motor Contactor Fail
- Phase Current Unbalance
- Under-current/Over-current Alarms
- Over Temperature - PTC Thermistor
- Optional Under-voltage
- Optional Insulation Test
- Optional PT-100 RTD Temperature Protection

3. Features

- Twenty three status messages
- IS Battery backed record of last 50 events
- Automatic or manual reset of motor overload
- Real time clock
- Display of Current, Temperature, Earth Leakage Current, Voltage, Overload Accumulator.
- Message Display to assist fault finding
- Optional Energy Storage Module
- Optional RS485 communication port interfaces to SCADA system via Modbus protocol.
- Optional EtherNet/IP communication port interface
- Optional analogue output 0-20 mA/4-20 mA

4. Application

The MPA Motor Protection Relay requires three current transformers to measure the three line currents. The measured currents are used to implement the following protection functions:

- a) Overload
- b) Short Circuit
- c) Phase Current Balance
- d) Residual Current

The motor overload function is based on calculations within the MPA's microprocessor, which simulates the motors thermal behaviour. The measured current signals provide the 'I²R' heating input to the simulation. The output of the simulation is the 'Thermal Accumulator'. A motor overload trip occurs when this value reaches 100%. The accumulator represents the simulated motor temperature.

The trip time is a function of the current and the selected trip time curve. The fifteen (15) motor overload curves provide trip settings from 3 to 40 seconds.

The three phase current signals are summed electronically in the relay to produce a residual current signal that can be used to detect earth fault currents. This feature is selectable and can be used in conjunction with the core balance earth leakage protection provided by the relay.

Short Circuit

The short circuit function has a definite time characteristic. If the current exceeds the selected level for the pre-set time then a trip occurs. The short circuit function trips the auxiliary relay. (The AUX relay is normally energised, and drops out when tripped).

The short circuit trip level is selected as a multiple of the selected full load current, from 3.0 to 10 times FLC, in steps of 0.5. A new "Off" option has been added to the S/C selections. This allows the use of external S/C protection methods.

Phase Current Balance

Phase current balance protection is selectable at 5%, 10%, 20%, 50% and off.

The phase current balance protection is inhibited until the average current exceeds both 20% of the selected full load current and the selected balance trip level.

Insulation Test

The optional MPA-I Module allows the insulation resistance of 415 V motors and/or installations to be tested with 500 VDC to earth. A selectable threshold allows an alarm to be triggered if the resistance to earth is too low. This test can only be performed when the motor is not running. An external 'Insulation Test Enable' must also be closed to allow a test to be performed.

A test is activated by closure of the digital input (DI1). The test takes 3 seconds. At the end of the test, the measured resistance is compared to the selected threshold. If the result is below this level an alarm will be triggered. The measurement range goes up to 120 MΩ.

The trip and alarm thresholds are selectable in the range 1.0 to 100 MΩ.

Specifications

Auxiliary Supply Volts:

240 VAC ± 20%, 50 Hz ± 2Hz
110 VAC ± 20%, 50 Hz ± 2 Hz

Earth Leakage Protection:

Trip Setting: 100-500 mA and 'OFF' (with approved 100:1 Toroid)
Time Delay: 155 ms – 475 ms

Residual Current:

Trip Setting: 10% - 100% FLC and Off
Time Delay: 100 ms – 5 Sec

Overload Protection:

Current Range: 5.125 A – 640 A (In 224 values across the range. Steps 1.6% - 3%)

6 x I Trip Time: 3,4,5,6,7, 8,10,12,14,16,20,24,28,32 & 40 Seconds

S-Cool Ratio: 1.0, 1.5, 2.0, 2.5, 3.0, 4.0, 5.0

O/L Reset Level: 30%, 40%, 50%, 60%, 70%, 80% 90%

Current Balance:

Trip Settings: 5%, 10%, 20%, 50% and Off

Short Circuit Protection:

Trip Setting: 3.0 x to 10.0 x FLC 0.5 increments

Trip Time: 20, 40, 60, 80, 100, 120, 160 ms and Off.

Under-voltage Protection:

Trip Setting: Selectable from 40% to 95% and Off

Trip Delay: 1.5 Sec

Insulation Test:

Selectable from 1.0 to 100 Meg.ohm and Off

RTD Temperature Protection:

Trip: Selectable from 60°C to 200°C and Off. Time Delay: 2 Sec

MPA Standard Alarms:

High Current: Selectable from 100% to 600% and Off
Time Delay: 1 Sec

Overload: Selectable from 50% to 95% and Off. Time Delay: 2 Sec

Under Current: Selectable from 32% to 96% and 'Off'. Time Delay: 2 Sec

Earth Leakage: 20%, 50% and 80%. Time Delay: 1Sec

Serial Communications:

Two different optional monitoring modules are available providing the user with a choice of RS485 Modbus RTU or EtherNet/IP

Dimensions (mm):

Escutcheon: 155 x 155

Case: 132 W x 132 H x 113 D

Cut out: 135 x 135

Relay Contacts:

MTR: 1 N/O 5A/250 VAC, 1 C/O 5A/250 VAC

ALM, AUX: 1 N/O 5 A/250 VAC

Base Models and Options Part Numbers

MODEL DESCRIPTION	Auxiliary Supply Voltage	Optional Monitoring Modules		Serial Communications Option		PART NUMBER
		Insulation Test	Over-Temp	Ethernet/ IP	RS485 Modbus	
MPA3V06.2 Std/ 110	110	X	X	X	X	120366
MPA3V06.2 I/ 110	110	YES	X	X	YES	120368
MPA3V06.2 M/ 110	110	X	YES	X	YES	120369
MPA3V06.2 IM/ 110	110	YES	YES	X	YES	120371
MPA3V06.2 IM(e)/ 110	110	YES	YES	YES	X	143095
MPA3V06.2 IM(e)/ 240	240	YES	YES	YES	X	143096

101658 Toroid 60 mm ID
115430 Toroid 85 mm ID
101656 Toroid 112 mm ID
101272 1000/1 45mm ID Current Transformers (3 Required)

} Earth leakage Toroid to be specified at time of order placement

AMPCONTROL ELECTRONICS

Ampcontrol CSM Pty Ltd ABN 35 000 770 141
7 Billbrooke Close CAMERON PARK NSW 2285
Phone: (02) 4903 4800
Fax: (02) 4903 4888
E-mail: electronicsorders@ampcontrolgroup.com
Web site: www.ampcontrolgroup.com

